

### DISMANTLING AT THE BENCH

1

### CYLINDER HEAD

- Dismantling and checks 13
- Valves 16
- Valve guides 17
- Valve springs 20
- Tappets 21
- Camshaft 22
- Adjusting valve clearances 26
- Tightening cylinder head 28

### COUNTER SHAFTS

- Vibration damping system with counter shafts 30
- Assembly 32

### TIMING GEAR

36

- Adjusting valve timing 38
- Adjusting timing belt tension 39
- Positioning counter shafts 40
- Adjusting timing belt tension 41

### SPECIAL TOOLS

43

### TORQUE WRENCH SETTINGS

44




*For matters not dealt with in this section, refer to the 2000 i.e. - 2000 i.e. turbo Section of the "Lancia petrol engine overhaul" manual.*



### SEQUENCE OF OPERATIONS

- Drain the engine oil (using spanner 1850113000) while the engine is raised off the ground by the hoist;
- mount the engine on the rotating stand using brackets 1861001011;
- remove the parts illustrated below:



# Engine

## Dismantling at the bench


2000 i.e. 16V 2000 i.e. 16V turbo

10.

\*




PW002H601




PW002H602




PW002H603




PW002H604




PW002H608



PW002H605




PW002H607



PW002H606

\* 2000 i.e. 16V engine only






# Engine



## Dismantling at the bench

2000 ie 16V 2000 ie 16V turbo

10.







*The sprocket bolt has a left-hand thread.*

To remove the sprocket bolt, use the flywheel locking tool 1867029000










# Engine




## Dismantling at the bench

2000ie 16V 2000ie 16V turbo

10.

















# Engine

## Dismantling at the bench


2000 ie 16V 2000 ie 16V turbo

10.





The sensor bracket should never be removed






# Engine


## Dismantling at the bench

2000 i.e. 16V 2000 i.e. 16V turbo


### 10.



PW010H601




PW010H602




PW010H607


PW010H603



PW010H606



PW010H604



PW010H605



\*

\* 2000 i.e. 16V turbo engine


### Numbering on cylinder block and bearing caps

The numbers stamped on the cylinder block and bearing caps must be the same and legible from the flywheel side.


The bearing cap positions are indicated by a series of notches starting from the timing gear side.



PW011H604




PW011H601



PW011H603



### 10.




*After dismantling the engine, carefully check the various dismantled parts.*

*The following sections contain instructions for the main checking and measuring operations necessary in order to determine whether the components are suitable for reuse.*


*The correct refitting sequences are also described, and special tools are indicated to facilitate the engine reassembly procedure.*



PW012H602



PW012H603




2H604

#### **Location of piston lubricating and cooling jets**


The spray jets are screwed into a special lubricating passage in the cylinder block.

**NOTE** *The arrow shows the point to be staked.*


### DISMANTLING AND CHECKS



Mounting cylinder head on tool 1860456000




Dismantling side covers from camshaft rear caps




Dismantling camshaft caps and lubrication pipes




### 10.




Dismantling camshafts



Dismantling tappets




Dismantling half collets, caps, springs, valves



PW015H601

**Decarbonizing and cleaning valve seats and passages**




PW015H602

### Refacing cylinder head

Slight refacing of the cylinder head is permitted.

However, if the combustion chamber depth then becomes less than 15.4 mm, the cylinder head should be replaced since it could give rise to damage to the valve seats.



PW015H603

### Measuring combustion chamber volume (41.8 cc)


After refacing the cylinder head, check the combustion chamber volume after fitting the valves and spark plugs.

Fill a measuring cylinder with VS 20 or 30 engine oil and note the amount put in, then allow the oil to stand in the cylinder for approx. 10 minutes.

After filling the combustion chamber, allow the oil to stand in the measuring cylinder for approx. 10 minutes.

Measure the remaining oil: the difference in the cylinder contents before and after filling the chamber corresponds to the volume of the chamber.


### 10.



#### Areas for removal of material *41.8cc*

If the measurement is less than 00.0 cc material should be removed from inside the chamber in order to obtain the correct value.

The arrows in the photo show the areas where material should be removed.




#### VALVES



#### Decarbonizing valves

Check that the valve stem does not show signs of scoring or seizure; also check using a micrometer that the valve stem diameter is within the tolerance limits.




#### Valve regrinding using a cutter

Set the scale to an angle of  $45^{\circ}30'$  and regrind the valve, removing as little material as possible. If the top of the valve stem is pitted, regrind it, again removing as little material as possible.



### Checking dimension (X)


After regrinding check that the thickness (X) of the valve on the head perimeter is at least 1 mm, otherwise the valve will need to be renewed.



PW017H603  
PW017H604


### Checking clearance between valve stem and valve guide

**NOTE** *If the clearance (measured as illustrated) between valve stem and valve guide is over 0.25 mm, the valve guide should also be renewed.*



PW017H601

### VALVE GUIDES




1860395000

PW017H602

### Removing valve guide

### 10.




LANCIA

#### Fitting valve guide


Replacement valve guides are also available with oversized external diameter (0.05, 0.10 and 0.25 mm).

**NOTE** Before installing the new valve guides, heat up the cylinder head to 100° - 120°C.



#### Reaming valve guide inner surface


This should be done if slight distortion occurs during installation.




#### Regrinding valve seats in the cylinder head

**NOTE** The valve seats in the cylinder head should be reground whenever the valves or valve guides are reground or replaced.


W = Valve seat recut at 45° and reduced to the specified width.




Regrinding valve seat with 44° 30' cutter.



Reducing outer valve seat with 20° cutter.




Reducing inner valve seat with 75° cutter.



### Measuring valve's line of contact on its seating


**NOTE** *If the valve head is not centred in its cylinder head location, regrind the cylinder head seats accordingly. If centring is impossible, renew the valve seat.*



### Checking valve stem height after regrinding


**NOTE** *If the stem is too high, shorten it by grinding.*

## 10.



### Valve leak compression test

**NOTE** *The test is carried out with spark plugs fitted.*




### Fitting valve guide oil seals



*Lubricate the parts with engine oil before final assembly.*


## VALVE SPRINGS



### Checking valve spring load

**NOTE** *Before assembly, the inner and outer valve springs should be checked to ensure that the minimum loads are within the specified limits.*





Fitting valve, caps, inner and outer springs and split taper collets

### TAPPETS


36,975 ÷ 36,995



### Checking tappet diameter

If a tappet shows excessive out of round, it should be renewed.

PW021H602



### Fitting tappets


If the tappet location is excessively worn, renew the cylinder head.



*Lubricate the parts with engine oil before final assembly.*

PW014H602

### 10.




#### CAMSHAFT



#### Measuring camshaft journals


**NOTE** *The cam and journal surfaces must not show signs of seizure or scoring, otherwise the camshaft will have to be renewed.*



#### Measuring cam height




*The camshaft must be renewed even if only one cam is excessively worn.*




#### Installing camshaft




Numbering inlet valve camshaft caps on cylinder head



Numbering inlet valve camshaft caps




**NOTE** *To prevent difficulties in camshaft rotation, the caps must be fitted exactly as illustrated in the photos.*



Numbering exhaust valve camshaft caps on cylinder head

Numbering exhaust valve camshaft caps


10.



19,950 ÷ 20,020

Measuring thickness of camshaft rear thrust cap


PW024H601



2,5 daNm

Fitting camshaft cap bolts and tightening by torque wrench

PW024H602




0,080 ÷ 0,230

Checking camshaft endfloat


PW024H603






Fitting camshaft front cap oil seal

PW025H601



Fitting camshaft rear cap side covers


PW025H602



Provisional assembly of camshaft sprockets

PW025H603

10.



**ADJUSTING VALVE CLEARANCES**

Checking clearance between tappet and camshaft cam




$0,38 \pm 0,03$   
 $0,43 \pm 0,03$




16V turbo



$0,35 \pm 0,04$   
 $0,40 \pm 0,04$



Mounting pressure lever 1860443000




Positioning tappet locking tool 1860747000

Position the cuts on the tappet edges so as to facilitate the subsequent withdrawal of shims to be replaced.




LANCIA



**Withdrawing tappet adjustment shim using a scribe and magnet**


**NOTE** *Replace the shim with another of appropriate thickness to obtain the correct valve clearance.*



**Fitting cylinder head gasket**


**NOTE** *Place the cylinder head gasket on the block with the word "ALTO" facing the fitter.*

*The cylinder head gasket is of the AS-TADUR type. Because of the special material from which it is made, it undergoes a polymerization process during engine operation, so it hardens considerably during use.*



PW027H603

### 10.




#### Fitting cylinder head



The following precautions are necessary to ensure polymerization of the cylinder head gasket:



- keep the gasket sealed in its nylon wrapper;
- do not unwrap until just before assembly;
- do not lubricate or dirty the gasket with oil, and make sure that the cylinder head and block surfaces are thoroughly clean.



#### TIGHTENING CYLINDER HEAD

The correct cylinder head bolt tightening procedure is as follows, bearing in mind that for each stage, the tightening sequence is as illustrated below:

- lubricate the bolts and washers and leave them to drain for at least 30 minutes;
- initially tighten the bolts to 2 daNm;
- tighten to 4 daNm using a torque wrench
- with an ordinary tommy bar, tighten the bolts again by an angle of 180° in two separate stages (90° + 90°), following the correct order at each stage.



Pre-tightening cylinder head bolts with torque wrench in two stages (2 + 2 daNm)





The ASTADUR gaskets are used with cylinder head bolts of the **yield point** type.

These bolts should be renewed after being used 4 times.



Angle tightening cylinder head bolts in two stages ( $90^\circ + 90^\circ$ )


**NOTE** Since an *ASTADUR* gasket is used, the cylinder head bolts need not be re-tightened after 1000-1500 km.



Fitting camshaft sprocket rear cover



11,8 daNm



Fitting and tightening camshaft sprocket bolts by torque wrench

# 10.

## VIBRATION DAMPING SYSTEM WITH COUNTER SHAFTS

In addition to forces on the piston crowns, caused by expanding gases, the following are present in internal combustion engines:

- centrifugal inertial forces, resulting from the rotating masses;
- 1st and 2nd order alternating inertial forces, resulting from the masses with alternating motion.


The purpose of balancing the engine is to eliminate the vibrations caused by these imbalances during operation.

The imbalances caused by centrifugal forces and 1st order alternating inertial forces are eliminated by suitably counterweighting the crankshaft.

The imbalance caused by 2nd order alternating inertial forces, is not usually eliminated in 4 in-line engines; it is left to the engine bearings to partially absorb it.

This engine instead adopts a system which cancels the vibrations caused by these forces; it comprises 2 counter-rotating shafts, with eccentric weights, located in the cylinder block.


The counter shafts are driven by a special double-sided toothed belt and set of sprockets which enable a speed double that of the crankshaft, and perfect synchrony with the latter, to be obtained.



Vibration damping system

## 10.


Diagrams representing the 2nd order alternating inertial forces and the balancing weights in the principal operating positions



10.




ASSEMBLY



PW032H601


Fitting counter shafts



PW032H602

PW032H603

Fitting counter shaft front bearings




PW032H604


PW032H605

Fitting counter shaft rear bearings





Fitting protective caps on counter shaft rear bearings




Fitting left counter shaft oil seal

PW033H602




2,3 daNm



PW033H603


Fitting left counter shaft cover bolts and tightening to correct torque

### 10.



PW034H601


Fitting right counter shaft oil seal



2,3 daNm

PW034H602


Fitting right counter shaft cover bolts and tightening to correct torque



PW034H603


Components of the vibration damping system with counter shafts

**2,5 daNm**




Fitting water pump bolts and tightening to correct torque

**11,8 daNm**




Fitting left counter shaft sprocket and tightening to torque

**11,8 daNm**




Fitting right counter shaft sprocket and tightening to torque

10.




Fitting timing belt tensioner

NOTE *Provisionally tighten the bolt*



Fitting counter shaft belt tensioner

NOTE *Provisionally tighten the nut*




14,2 daNm


Fitting flywheel bolts and tightening to torque

### Mounting crankshaft rotating handle


**NOTE** *The pair of studs 1867028000 may be mounted instead of the handle*



### Fitting crankshaft sprocket




### Fitting rocker cover






### 10.



#### ADJUSTING TIMING



Position the camshaft sprockets so that the notches on the rear of the sprockets line up with the bottom tips of the slot on the rocker cover. Turn the crankshaft until the crankshaft sprocket reference mark is lined up with the projection on the front cover.



**NOTE** Every 20,000 km visually check the condition of the timing belt and renew it if it is:

- soaked in oil or coolant;
- cracked or with broken teeth;
- frayed or with a worn tooth profile.

It must be renewed if dismantled during repair work.



#### Fitting timing belt

When fitting the timing belt, check that the teeth are properly engaged on all the sprockets.

**NOTE** To avoid damaging the belt fibres during assembly of the timing belt, take the utmost care not to bend it into tight angles.


## ADJUSTING TIMING BELT TENSION

Fit part 1860745200 onto tool 1860745100, then position the weight, without the knurled part, at 100 mm on the graduated rod and secure it.


Mount the tool thus prepared on the belt tensioner as illustrated in the photo, then adjust the joint to position the graduated bar on the horizontal.

Bed in the belt by turning the crankshaft two revolutions in its direction of rotation and tighten the belt tensioner bolt.

**NOTE** *During the final stage, the graduated bar may move from its horizontal position; if this occurs, readjust the joint to set the bar in its original horizontal position and repeat the procedure.*



**4,4 daNm**



**Tightening belt tensioner bolt to torque**


**19 daNm**




**Fitting counter shaft sprocket bolt (left-hand thread)**



*Check that the valve timing is correct and position the counter shaft sprocket so that the reference mark is facing upwards.*



## 10.






### POSITIONING COUNTER SHAFTS

Position the counter shaft sprockets so that their reference marks are lined up with the reference on the water pump for the left counter shaft, and the reference on the sheet steel cover for the right counter shaft.

Also make sure that the reference on the counter shaft sprocket located on the crankshaft is facing upwards.

**NOTE** *Visually examine the condition of the timing belt every 20,000 km, and renew it if it is:*

- soaked in oil or coolant;
  - cracked or with broken teeth;
  - frayed or with a worn tooth profile.
- It must be renewed if dismantled during repair work.*



### Fitting counter shaft drivebelt

When fitting the timing belt, check that the teeth are properly engaged on all the sprockets.


**NOTE** *To avoid damaging the belt fibres during assembly of the timing belt, take the utmost care not to bend it into tight angles.*

### ADJUSTING TIMING BELT TENSION


Fit part 1860745200 to tool 1860745100, then position the weight, without the knurled part, at 205 mm on the graduated bar and secure it.

Mount the tool thus prepared on the belt tensioner as illustrated in the photo, then adjust the joint to position the graduated bar on the horizontal.

**NOTE** *During the final stage, the graduated bar may move from its horizontal position; if this occurs, readjust the joint to set the bar in its original horizontal position and repeat the procedure.*




PW041H601



PW041H602

2,3 daNm 




PW041H603

Tightening belt tensioner bolt to torque

## 10.

### LONGITUDINAL SECTION OF 2000 i.e. 16V ENGINE





<b>1840207814</b>	Part (Ø 18-22 mm) for removing counter shaft front bearings from the block (use with 1840206000)	<b>1860644000</b>	Tool for removing and refitting valves
<b>1850088000</b>	Spanner (13 mm) for manifold nuts	<b>1860699000</b>	Drift for fitting crankshaft rear oil seal (use with 1870007000)
<b>1850113000</b>	Spanner (12 mm) for engine oil drain plug	<b>1860745100</b>	Tool for adjusting timing belt tension (use with specific parts)
<b>1852137000</b>	Spanner, 1/2" attachment, for cylinder head bolts	<b>1860745200</b>	Part for adjusting timing belt tension (use with 1860745100)
<b>1852150000</b>	Spanner for rocker cover bolts	<b>1860745400</b>	Part for adjusting counter shaft belt tension (use with 1860745100)
<b>1853003000</b>	Spanner (19 mm) for camshaft sprocket bolt, on vehicle	<b>1860747000</b>	Tool for locking tappets while replacing shims during valve clearance adjustment (use with 1860443000)
<b>1854033000</b>	Spanner for electric fuel pump or tank fuel filter retainer	<b>1860757000</b>	Tool for removing cartridge oil filter
<b>1854038000</b>	Spanner for fuel gauge sender retainer	<b>1860768000</b>	Part for rotating crankshaft in vehicle
<b>1860054000</b>	Drift (Ø 22 mm) for removing and refitting small end bush	<b>1860769000</b>	Board for supporting cylinder head during valve removal and refitting
<b>1860162000</b>	Pressure gauge with connections for checking oil pressure (0-9.81 bar scale)	<b>1860770000</b>	Drift for fitting camshaft oil seals and crankshaft front oil seal
<b>1860183000</b>	Pliers (Ø 75-110 mm) for removing and refitting piston rings	<b>1861001011</b>	Pair of brackets securing engine to rotating stand 1861000000
<b>1860303000</b>	Tool for fitting gudgeon pin circlips	<b>1867028000</b>	Pair of threaded pins for rotating crankshaft (at the bench)
<b>8860443000</b>	Pressure lever for inserting tool for locking tappets during valve clearance adjustment	<b>1867029000</b>	Flywheel locking tool
<b>1860395000</b>	Drift for removing valve guides	<b>1867030000</b>	Tool for locking flywheel while removing/refitting crankshaft sprocket nut, manual gearbox
<b>y860454000</b>	Tool for fitting valve guide oil seals	<b>1876036000</b>	Lead with contacts for turning engine during valve clearance adjustment
<b>1860456000</b>	Tool for supporting cylinder head during tappet shim replacement (operation using vice)	<b>1890385000</b>	Sleeper (Ø 7 mm) for valve guide bores
<b>1860470000</b>	Tool for supporting cylinder head during overhaul	<b>1895362000</b>	Cooling system leak tester
<b>1860473000</b>	Tool for locking camshaft sprocket or auxiliary components sprocket	<b>1895683000</b>	Cylinder compression tester (4.05 - 18.2 bar scale)
<b>1860486000</b>	Drift for fitting valve guides	<b>1895683002</b>	Cards for device 1895683000
<b>1860490000</b>	Tool for supporting valve seal tester 1895868000 (use with 1860470000)	<b>1895762000</b>	Dynamometer for checking V-belt and poly-V belt tension
<b>1860592000</b>	Universal hook for hoisting and transporting engine/gearbox unit	<b>1895868000</b>	Valve leak tester
<b>1860592010</b>	Part for removing and refitting engine/gearbox unit (use with 1860592000)	<b>1895890000</b>	Pressure gauge with connections for measuring electric pump supply pressure
<b>1860605000</b>	Sleeve (Ø 60-125 mm) for installing standard and oversize pistons in cylinders	<b>1895890030</b>	Connections for measuring electric fuel pump supply pressure (use with 1895890000)

# Engine

## Torque wrench settings



### 10.



PART	Thread	Torque wrench settings	ENGINE	
		daNm	16V	16V turbo

Central bearing cap bolt	M 12 x 1.25	2 + 130°	●	●
Bearing cap self-locking bolt	M 12 x 1.25	2 + 90°	●	●
Belt cover bolt	M 8	2.3	●	●
Crankcase breather bolt	M 8	2.3	●	●
Flywheel bolt	M 12 x 1.25	14.2	●	●
Big end bearing cap bolt	M 10 x 1	2.5 + 50°	●	●
Cylinder head bolt	M 10 x 1.25	4 +90° +90°	●	●
Inlet manifold nut	M 8	2.5	●	●
Exhaust manifold nut	M 8	2.5	●	
Bolt securing exhaust manifold bracket to manifold	M 8	2.5	●	●
Exhaust manifold bracket bolt	M 10 x 1.25	5	●	●
Bolt securing crankshaft sprocket and pulley	M 14 x 1.5 Left-hand	19	●	●
Camshaft sprocket bolt	M 12 x 1.25	11.8	●	●
Belt tensioner nut	M 10 x 1.25	4.4	●	●
Accelerator bracket bolt	M 8	2.5	●	●
Accelerator link nut	M 8	2.5	●	●
Self-locking nut securing turbocompressor to exhaust manifold	M 10 x 1.5	5.9		●
Self-locking nut securing flange to turbocompressor	M 8	2.9		↙



# Engine Torque wrench settings


## 10.

PART	Thread	Torque wrench settings	ENGINE	
		daNm	 16V	 16V turbo

Bolt securing turbocompressor bracket to exhaust manifold	M 10 x 1.25	5.9		●
Bolt securing oil discharge pipe to bracket	M 8	2.3		●
Bolt securing complete cover to cylinder block	M 8	2.3		●
Bolt securing cover to bracket	M 8	2.3		●
Oil filter mounting bolt	M 10 x 1.25	4.9	●	●
Bolt securing water pump to cylinder block	M 8 x 1	2.5	●	●
Bolt securing water pump pulley	M 8	2.3	●	●
Bolt securing exhaust manifold bracket to cylinder block	M 8	2.5	●	●
Self-locking nut securing exhaust manifold to cylinder head	M 8 x 1.25	2.9		●
Nut securing exhaust manifold bracket to cylinder block	M 8	2.5	●	●
Nut securing thermostat to cylinder head	M 8	2	●	●
Bolt securing alternator to bracket	M 12 x 1.25	6.9	●	●
Bolt securing oil filter mounting to alternator bracket	M 12 x 1.25	6.9	●	●
Nut securing oil filter mounting to alternator bracket	M 12 x 1.25	6.9	●	●
Bolts securing alternator belt tension adjustment brackets	M 8	3.4	●	●
	M 10 x 1.25	4.3	●	●
Bolt securing driveshaft mounting to cylinder block	M 10 x 1.25	5	●	●
	M 8	2.5	✓	●

# Engine

## Torque wrench settings



### 10.

PART	Thread	Torque wrench settings	ENGINE	
		daNm	16V	16V turbo
Nut securing driveshaft mounting to cylinder block	M 10 x 1.25	5	●	●
Bolt securing power steering pump bracket	M 8	2	●	●
Bolts securing bracket to power steering pump	M 10 x 1.25	5	●	●
	M 8	2	●	●
Bolt securing camshaft caps	M 8 x 1.25	2.5	●	●
Nut securing alternator bracket to cylinder head	M 8	2	●	●
Bolt securing idler gear housing bracket to cylinder head	M 12 x 1.25	9.5	●	●
Nuts securing bracket to power steering mounting	M 8	5	●	●
	M 10 x 1.25	5	●	●
Bolt securing oil sump to mounting	M 6	1	●	●
Bolt securing top and bottom of inlet pipe	M 8	2	●	●
Bolt securing bracket to power steering mounting	M 10 x 1.25	5	●	●
Spark plugs	M 14 x 1.25	3.7	●	●
Bolt securing alternator to bracket	M 10 x 1.25	7	●	●
Nut securing alternator to bracket	M 10 x 1.25	7	●	●
Oil pressure warning sender	M 14 x 1.5	3.7	●	●
Oil temperature warning sender	M 14 x 1.5	3.7	●	●
Water temperature sender	M 16 x 1.5 tapered	3	✓	●



# Engine Torque wrench settings

## 10.


PART	Thread	Torque wrench settings	ENGINE	
		daNm	16V	16V turbo

Oil level warning sender	M 12 x 1.25	2.5	●	●
Oil sump plug	M 22 x 1.5	5	●	●
Bolt securing counter shaft sprocket	M 12 x 1.25	11.8	●	●
Bolt securing counter shaft cover	M 8	2.3	●	●
Nut securing counter shaft belt tensioner	M 8	2.3	●	●
Bolt securing cover for counter shaft radial seal support	M 8 x 1.25	2.4	●	●
Connection securing oil delivery pipe to turbine	M 22 x 1.5	5	●	●


Position the vehicle on a lift.

Then, proceed as follows;


- drain the coolant;
- remove the bonnet lid;
- disconnect the negative lead from the battery;
- remove the items illustrated below:




P1L01AJ01




P1L01AJ02



P1L01AJ03




P1L01AJ05




P1L01AJ04









18.



Raise the vehicle and carry out the following operations, from underneath:








In order to extract the cooling radiator it must be disconnected from the duct






The numbers at the side of the illustrations indicate the order in which the operations should be carried out

10.




P1L04AJ04




Pipes connecting over-boost solenoid valve to wastegate valve and turbocharger



P1L05AJ01




P1L05AJ02




P1L05AJ03


Coolant hose between turbocharger and radiator




P1L05AJ05



P1L05AJ04




P1L05AJ06




P1L05AJ07

Remove the clutch release operating cylinder and bracket and place it in the engine compartment without removing the oil pipe

### 10.




P1L06AJ01




P1L06AJ02




P1L06AJ03




P1L06AJ04




P1L06AJ05




P1L06AJ07



P1L06AJ06




P1L06AJ08



P1L06AJ09

Fuel supply pipe and electrical connection for engine rpm and TDC sensor




P1L07AJ02




P1L07AJ01

Oil pipes from power assisted steering pump

Electrical connection for detonation sensor




P1L07AJ03




P1L07AJ04



Electrical connection for coolant temperature sensor (for I.A.W. ignition/injection)




P1L07AJ05



P1L07AJ06

Fuel return pipe from pressure regulator




P1L07AJ07

Electrical connections for injectors



### 10.




P1L08AJ01




P1L08AJ02



P1L08AJ03




P1L08AJ04




P1L08AJ05


In order to facilitate the removal of the radiator, the front bumper must be moved forwards; in addition, the radiator must be disconnected from the engine oil cooling radiator as well as from the cross member




P1L08AJ06



P1L08AJ07








P1L08AJ08




P1L08AJ09


- remove the front wheels and remove the right side wheel arch liner;
- raise the lift and, from underneath the vehicle, drain the gearbox oil; then carry out the following operations:




### 10.




P1L10AJ01




P1L10AJ02







P1L10AJ03



P1L10AJ04





P1L10AJ05





P1L11AJ03


- disconnect the electrical connections from the alternator and from the starter motor



P1L11AJ06





P1L11AJ08











P1L11AJ09

10.




- disconnect the gear engagement and selector rods adjusting the nuts and bolt shown by the arrows








### 10.




P1L14AJ02

P1L14AJ01




P1L14AJ03

- loosen the bolts fixing the support brackets to the gearbox;
- lower the lift, position the universal hook 186059200 in the special brackets on the power unit : then, using the hoist, place the engine under slight pressure;



P1L14AJ04




P1L14AJ05

- remove the engine side flexible mounting from the support bracket, acting on the bolts (1); then, remove the bolts shown by the arrows, which fix the support bracket to the bodyshell;



P1L14AJ07




P1L14AJ06






- remove the support brackets from the gearbox and from the flexible joint;



- Remove the rod anchoring the engine to the bodyshell



- lower the power unit to the ground and release the hoist  
- raise the vehicle and extract the power unit


# Engine



## Removing-refitting power unit

DELTA HF integrale 16v

### 10.


- rest the engine on a support and then remove the items illustrated below:






P1L17AJ02



P1L17AJ01



P1L17AJ03




P1L17AJ04




P1L17AJ06




P1L17AJ07




P1L17AJ08




P1L17AJ12



P1L17AJ19



P1L17AJ10




P1L17AJ11



P1L17AJ13

**NOTE** To refit the power unit simply reverse the order of the operations carried out for its removal

DIAGRAM SHOWING OPERATION OF FUEL SYSTEM




1. Electric fuel pump, located inside tank on flexible mounting.
2. Gauze pre-filter
3. Electric pump - pre-filter container
4. Ring nut fixing fuel passage device
5. Spring fixing electric pump container

6. Fuel manifold supply to the injectors
7. Pipe connecting vacuum pump to fuel pressure regulator
8. Fuel pressure regulator
9. Fuel filter
10. Fuel return pipe from pressure regulator to tank

11. Fuel supply pipe from the tank to the filter
12. Fuel level gauge
13. Fuel tank
14. Fuel tank ventilation and breather pipe

DIAGRAM SHOWING LUBRICATION SYSTEM



1. Lobe gear oil pump
2. Oil pressure relief valve
3. Strainer with gauze filter
4. Oil pressure sender unit
5. Oil temperature sender unit
6. Switch signalling insufficient oil pressure
7. Plug for oil radiator thermostatic by-pass valve
8. Oil return pipe from cooling radiator to thermostatic valve
9. Oil supply pipe from thermostatic valve to cooling radiator
10. Engine oil cooling radiator
11. Oil return duct from turbocharger to sump
12. Main duct supplying oil under pressure to turbocharger
13. Full flow cartridge oil filter with safety valve for cutting out filter if filter element is blocked
14. Main duct supplying oil under pressure to various components
15. Piston cooling oil jets

The piston cooling jets (15) have a built in ball valve which opens at a pressure of 1.25 - 1.75 bar.

If it is not working properly, replace the jet

The thermostatic valve, located in the oil filter mounting, has the following function:

a) when the temperature is below  $78 \pm 2^\circ\text{C}$ , the oil passes directly into the cartridge filter and returns to the engine.

b) when the temperature is above  $83,5^\circ$  the thermostatic valve is open and allows the oil to pass into the cooling radiator and lower the temperature thus guaranteeing improved lubrication.



The thermostatic valve is not available as spares; if it is not working properly, replace the complete oil filter mounting.




Supply circuit



Return circuit

DIAGRAM SHOWING I.A.W. (M.P.I.) INJECTION/IGNITION SYSTEM



P1L25AJ01

1. Fuel tank
2. Electric fuel pump
3. Fuel filter
4. Fuel manifold
5. Fuel pressure regulator
6. Intake air absolute pressure sensor
- 6A. Intake air absolute pressure sensor
7. HT distributor with injection timing sensor
8. Butterfly valve position sensor
9. Intake air temperature sensor
10. Rpm and TDC sensor
11. Electronic control unit
12. Injectors
13. Battery
14. Ignition switch
15. Injection ignition relay feeds
16. Supplementary air solenoid valve for automatic engine idle adjustment
17. Coolant temperature sensor
18. Spark plugs
19. Ignition coil with power module
20. Butterfly valve
21. Diagnostic socket
22. Fuse
23. Connector block
24. Over-boost solenoid valve
25. Intake air duct from the filter
- 25A. Detonation sensor
26. Compressed air ducts from turbocharger
27. Supercharging adjustment actuator (waste-gate valve)

**Foreword**

The I.A.W. injection/ignition system fitted on the Delta HF integrale 16 V is similar to the one fitted on the Delta Hf integrale.

However, certain small modifications have been made to further improve the reliability of the system with the resulting differences: 1 - The use of two absolute pressure sensors rather than one. 2 - A different over-boost solenoid valve with a consequently different intervention strategy. 3 - A different location for the detonation sensor on the cylinder head. 4 - A different butterfly valve control mechanism on the butterfly casing.

**NOTE** *This section only deals with the variants compared with the I.A.W. system fitted on the Delta HF Integrale which has been extensively covered in section 10 of this binder*

10.

Injection/ignition system (I.A.W) wiring diagram

- 6. Timing sensor
- 8. Coolant temperature sensor (I.A.W.)
- 9. Detonation sensor
- 9/A Over-boost solenoid valve
- 14. Connector block
- 19. Solenoid air valve (V.A.E.)
- 20. Rpm and TDC sensor
- 22. Ignition distributor
- 23. Spark plugs
- 24. Fuel injectors
- 31. Connector block
- 32. Connector block
- 34. Connector block
- 35. Battery
- 42. Ignition coil with power module
- 44. Earth on engine
- 47. Butterfly valve position sensor
- 49. Air temperature sensor
- 50/A. Absolute pressure sensor
- 50/B. Absolute pressure sensor
- 55. Injector relay feed
- 56. Electric fuel pump relay feed
- 59. Instrument panel
  - D. System failure warning light (I.A.W.)
- 62. Connector block
- 62/B. System protective fuse (I.A.W.)
- 72. Connector block
- 75/A. Connector block
- 90. Diagnostic socket
- 100. Ignition switch
- 116. Injection/ignition electronic control unit - (I.A.W.)
- 117. Connector
- 117/A. Connector
- 142. Electric fuel pump
- 153. Rear earth cable loom









DIAGRAM SHOWING OPERATION OF COOLING SYSTEM




P1L23AJ01 P1L23AJ02

- 1. Engine coolant radiator
- 2. Coolant hose between thermostat and radiator
- 3. Coolant hose between radiator and pump
- 4. Coolant hose between the radiator and the turbocharger
- 5. Coolant hose between turbocharger and pump
- 6. Coolant return hose to expansion tank
- 7. Controlled by-pass thermostat for coolant mixture

- 8. Water pump
- 9. Expansion tank
- 10. Coolant hose between the car interior heater-radiator and the pump
- 11. Coolant hose between thermostat and car interior heater-radiator
- 12. Car interior heater-radiator


 Supply circuit  
 Return circuit

BY-PASS THERMOSTAT CLOSED



P1L23AJ03 P1L23AJ04


BY-PASS THERMOSTAT OPEN




P1L23AJ05 P1L23AJ06

- 1. From the engine
- 2. Coolant temperature sender unit
- 3. To the by-pass
- 4. To the butterfly casing
- 5. To the car interior heater
- 6. To the expansion tank
- 7. To the coolant radiator

Location of absolute pressure sensors in engine compartment



P1L27AJ02



P1L27AJ01

### 1°) ABSOLUTE PRESSURE SENSORS


Two absolute pressure sensors are fitted on the Delta HF integrale 16 V version. They are connected by a rubber pipe (3) to the inlet manifold (4).

The pressure sensor (1) supplies a voltage signal proportional to the absolute pressure in the inlet manifold for pressure values up to 1600mmHg, whilst the other absolute pressure sensor (2) provides the signal for pressure values up to 2280mmHg. With the use of two absolute pressure sensors the signal is clearer since for pressures greater than 0.7 bar the sensor (1) is no longer sufficient to guarantee a clear signal reading. Therefore when the pressure in the inlet manifold exceeds 0.7 bar, the electronic control unit changes the signal reading to sensor (2).




*The base and cover of the sensor are different colours, one is black and the other is grey. If the sensors are removed-refitted, the same colour sensor and electrical connector must always be matched together.*

### 2°) OVER-BOOST DEVICE SOLENOID VALVE



P1L27AJ04




P1L27AJ03

Location on vehicle of over-boost solenoid valve

**10.**

**DIAGRAM SHOWING OVER-BOOST SOLENOID VALVE CONNECTION**



P1L28AJ01

**Operation of over-boost device**

The over-boost device solenoid valve (24) is permanently controlled by the injection/ignition electronic control unit via terminal (16). The description of the operation of the over-boost device is similar to that previously described in chapter 10 - fuel system - in this binder therefore a description of the operation of the over-boost solenoid valve (24) only follows.


The over-boost device solenoid valve (24) is a three-way A-B-C solenoid valve. Duct A is connected via sleeve (1) to the waste-gate valve actuator (27). Duct B via sleeve (2) is connected to the turbocharger excess pressure duct. Duct C is connected via sleeve (3) to the turbocharger intake duct. When the solenoid valve is not activated by the control unit, cylinder D closes duct C, leaving channels A and B in contact with one another, and the excess pressure arriving in duct B acts on the waste-gate actuator (27), thereby adjusting the excess supply pressure. When the solenoid valve is activated by the electronic control unit, cylinder D, magnetized by the coil winding, starts to pulse, controlled by a Duty-cycle signal, opening duct C for variable lengths of time; these opening frequencies vary according to sample curves memorized in the control unit and the pressure in the inlet manifold plus the engine load conditions.

The opening of duct C allows, via sleeve (3), part of the pressure to be discharged which was formerly acting on the waste-gate valve actuator (27) in the inlet manifold and the turbocharger thus creating the over-boost function.

**NOTE** *The Delta HF integrale 16 V version no longer has an over-boost warning light and instead there is an I.A.W. injection/ignition system failure warning light.*


### 3°) DETONATION SENSOR

Location of detonation sensor on cylinder head




### 4°) BUTTERFLY CASING

View of butterfly casing on vehicle



- 1) Lever for butterfly valve control cable attachment
- 2) Butterfly valve control lever
- 3) Engine idle speed adjustment screw
- 4) Attachment for coolant supply hose from butterfly casing heating motor.
- 5) Attachment for supplementary air supply hose from idle speed adjustment solenoid valve (V.A.E)
- 6) Attachment for coolant return hose from butterfly casing to engine.



P1L29AJ03



**REMOVING-REFITTING POWER UNIT** 1

### **FUEL SYSTEM**

- Diagram showing operation of fuel system 19

### **LUBRICATION**

- Diagram showing lubrication system 21

### **COOLING SYSTEM**

- Diagram showing operation of cooling system 23

### **FUEL SYSTEM**

- Diagram showing IAW (MPI) injection/ignition system 25

- Injection/ignition system (IAW) wiring diagram 26

- Absolute pressure sensors - Over-boost device solenoid valve 27

- Diagram showing connection of over-boost device solenoid valve 28

- Detonation sensor - Butterfly casing 29